





Quick Start Assembly/Install Instructions

CLEARSTREAM™ J-Mount

Before attaching the antenna to any surface, TEST RECEPTION in that area.

Connect the antenna to the TV or receiver and run a full channel scan.
If reception is not as desired, move the antenna and rescan TV/receiver.

Tools Required: Power Drill, 3/16" Drill Bit,
8 and 10mm Ratcheting Drivers, Medium-sized Cross Point Screwdriver.
Before beginning assembly, make sure all pieces needed are present.

| | | | |
|---|---|---------------------------|---|
| A |  | 1/4" x 50mm Mounting Bolt | 4 |
| B |  | 1/4" Hex Nut | 2 |
| C |  | 1/4" x 40mm | 2 |
| D |  | Roof Sealing Pads | 4 |

