

BT-2010

QFX

WHERE THE PARTY BEGINS™



INSTRUCTION MANUAL



1. **POWER SWITCH:** ON/OFF
2. **MODE:** change between functions (BT, USB/TF, FM Radio).
3. **PLAY/PAUSE:** In USB/FM/AUX modes, press to play and press to pause.
4. **TF CARD:** Insert TF Card with MP3 Formatted music tracks
5. **DC5V:** Charging port
6. **⏮:** In music playback mode, press to go to the previous song. Press and hold for volume down.
7. **⏭:** In music playback mode, press to go to the next song. Press and hold to increase volume.
8. **USB PORT:** USB Playback with MP3 Formatted music tracks.

In FM mode, press and hold to automatically search and save stations. This process may take two minutes to complete. Do not interrupt it until the search/save process has been completed. Then use PREV and NEXT buttons to change radio stations.

In Bluetooth mode, if there is an incoming call, press to answer/hang up the call. Press and hold for 3 second to automatically redial the recently called number.

1. **INTERRUPTOR DE ENCENDIDO:** ENCENDIDO/APAGADO
2. **MODOS:** cambio entre funciones (BT, USB/TF, Radio FM).
3. **REPRODUCIR/PAUSAR:** En los modos USB/FM/AUX, presione para reproducir y presione para pausar.
4. **TARJETA TF:** inserte la tarjeta TF con pistas de música formateadas en MP3
5. **DC5V:** puerto de carga
6. **⏮:** En el modo de reproducción de música, presione para ir a la canción anterior. Mantenga presionado para bajar el volumen.
7. **⏭:** En el modo de reproducción de música, presione para ir a la siguiente canción. Mantenga presionado para aumentar el volumen.
8. **PUERTO USB:** reproducción USB con pistas de música formateadas en MP3.

En el modo FM, mantenga presionado para buscar y guardar estaciones automáticamente. Este proceso puede tardar dos minutos en completarse. No lo interrumpa hasta que se haya completado el proceso de búsqueda/guardado. Luego use los botones ANTERIOR y SIGUIENTE para cambiar las estaciones de radio.

En el modo Bluetooth, si hay una llamada entrante, presione para responder/colgar la llamada. Mantenga presionado durante 3 segundos para volver a marcar automáticamente el número al que llamó recientemente.

1. **INTERRUPTEUR D'ALIMENTATION:** MARCHE/ARRÊT
2. **MODE:** basculer entre les fonctions (BT, USB/TF, radio FM).
3. **PLAY/PAUSE:** En modes USB/FM/AUX, appuyez pour lire et appuyez pour mettre en pause.
4. **CARTE TF:** insérez une carte TF avec des morceaux de musique au format MP3
5. **DC5V:** port de charge
6. **⏮:** En mode lecture de musique, appuyez pour aller à la chanson précédente. Appuyez et maintenez pour baisser le volume.
7. **⏭:** En mode lecture de musique, appuyez pour passer à la chanson suivante. Maintenez enfoncé pour augmenter le volume.
8. **PORT USB:** lecture USB avec des pistes musicales au format MP3.

En mode FM, maintenir pour rechercher et enregistrer automatiquement les stations. Ce processus peut prendre deux minutes. Ne l'intomez pas tant que le processus de recherche/enregistrement n'est pas terminé. Utilisez ensuite les boutons PREV et NEXT pour changer de station de radio.

En mode Bluetooth, s'il y a un appel entrant, appuyez pour répondre/raccrocher l'appel. Appuyez et maintenez pendant 3 secondes pour recomposer automatiquement le numéro récemment appelé.

BLUETOOTH

Toggle MODE to select BT mode on the BT-2010. On your Bluetooth-enabled device, turn Bluetooth on, pair it to "QFX BT-2010" and enjoy Bluetooth music from your device.

TWS

True Wireless Stereo (TWS) allows you connect two BT-2010 units together to play Bluetooth music in wirelessly in stereo. To set up TWS:

1. Push MODE button on both speakers until both speakers are in BT mode.
2. When both speakers are in BT mode, press ►|| button twice on one speaker only. You will hear a beep. Next time you put both speakers in Bluetooth mode at the same time, both speakers will connect automatically.

CHARGING

Plug in the USB cable to a 5VDC, 1 amp minimum source to recharge the internal battery. While charging, the rear tail lights will be solid red color. Once the unit is fully charged, the rear tail lights will be flashing.

CAUTION

Do not disassemble, short circuit, or expose UNIT to fire or hot temperatures. Recycle battery according to local state and national regulations.

BLUETOOTH

Alterne MODE para seleccionar el modo BT en el BT-2010. En su dispositivo habilitado para Bluetooth, active Bluetooth, conéctelo a "QFX BT-2010" y disfrute de la música Bluetooth desde su dispositivo.

TWS

True Wireless Stereo (TWS) le permite conectar dos unidades BT-2010 juntas para reproducir música Bluetooth de forma inalámbrica en estéreo. Para configurar TWS:

1. Presione el botón MODE en ambos parlantes hasta que ambos parlantes estén en modo BT.
2. Cuando ambos parlantes estén en modo BT, presione el botón ►|| dos veces en un solo parlante. Escuchará un pitido. La próxima vez que ponga ambos altavoces en modo Bluetooth al mismo tiempo, ambos altavoces se conectarán automáticamente.

CARGA

Conecte el cable USB a una fuente de 5 V CC, 1 amperio como mínimo para recargar la batería interna. Mientras se carga, las luces traseras traseras serán de color rojo sólido. Una vez que la unidad esté completamente cargada, las luces traseras parpadearán.

PRECAUCIÓN

No desarme, cortocircuite ni exponga la unidad al fuego o a altas temperaturas. Recicle la batería de acuerdo con las normas locales, estatales y nacionales.

BLUETOOTH

Basculez MODE pour sélectionner le mode BT sur le BT-2010. Sur votre appareil compatible Bluetooth, activez Bluetooth, associez-le à "QFX BT-2010" et profitez de la musique Bluetooth depuis votre appareil

TWS

True Wireless Stereo (TWS) vous permet de connecter deux unités BT-2010 ensemble pour lire de la musique Bluetooth sans fil en stéréo. Pour configurer TWS :

1. Appuyez sur le bouton MODE sur les deux haut-parleurs jusqu'à ce que les deux haut-parleurs soient en mode BT.
2. Lorsque les deux haut-parleurs sont en mode BT, appuyez ►|| deux fois sur le bouton d'un seul haut-parleur. Vous entendrez un bip. La prochaine fois que vous mettez les deux haut-parleurs en mode Bluetooth en même temps, les deux haut-parleurs se connecteront automatiquement.

MISE EN CHARGE

Branchez le câble USB sur une source de 5 VDC, 1 A minimum pour recharger la batterie interne. Pendant la charge, les feux arrière seront de couleur rouge solide. Une fois l'appareil complètement chargé, les feux arrière clignoteront.

MISE EN GARGE

Ne pas démonter, court-circuiter ou exposer l'appareil au feu ou à des températures élevées. Recyclez la batterie conformément aux réglementations locales et nationales.



LIMITED PRODUCT WARRANTY POLICY

Before returning your Product for service under this Warranty, please (i) read the instruction manual carefully and visit our website at www.qfxusa.com for Product updates and extended support documentation (e.g., Common Troubleshooting Guides); (ii) if you are still having trouble with your Product, please contact the QFX Customer Support Department.

Subject to the terms and conditions herein, QFX, Inc. (herein after called "QFX") warrants to the original purchaser of the Product ("Customer") that for the applicable Warranty Period listed below, the Product will be free from defects in material or workmanship under normal, non-commercial use ("Defects").

Warranty Period encompasses, as listed below, separate "Coverage Periods" for Parts and Labor, each Coverage Period to begin from the original date of Customer purchase. If Customer returns a defective Product (or any component thereof) during the applicable Warranty Period, QFX will, at its option, during the specified Coverage Periods for Parts and Labor (as applicable either: (i) repair the Product (or, as applicable, any component thereof) or (ii) replace the Product (or, as applicable, any component thereof) with a new or refurbished Product (or, as applicable, any component thereof), in either case free of charge to Customer for Parts and/or Labor (as applicable) during the specified Coverage Period only, and excluding applicable shipping charges (noted below), for which the Customer is responsible. The foregoing states the Customer's exclusive remedy and QFX sole liability for breach of the limited warranty contained herein.

This warranty covers only normal use. This warranty is not transferable. QFX is not responsible for warranty replacement should the QFX label or logo be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, immersion in liquids, improper installation, improper shipping, damage caused by disasters such as fire, flood, or service other than by QFX. In addition, this warranty excludes any Product (or, as applicable, any component thereof) that has been subject to or Defects resulting from: (a) any neglect or misuse by a Customer, an accident, improper application, violation of operating instructions for the Product, any other Customer-induced damage, or the alteration or removal of any Product serial number; (b) any modification or repair to Product (or, as applicable, any component thereof) by any party other than QFX or a party authorized in writing by QFX; (c) any damage to Product (or, as applicable, any component thereof) due to power surges, incorrect electrical voltage, misconnection to any device, or malfunction of any device used with the Product (or, as applicable, any component thereof); (d) cosmetic damage to the Product (or, as applicable, any component thereof) caused by normal wear and tear; (e) shipping damage that occurs while the Product is in transit; (f) damage caused by heat sources, sunlight, electromagnetic conditions, or other climatic conditions or (g) any acts of God.

Product is sold to Customer for personal, non-commercial use only. Product is not warranted for Customer's commercial or rental use. In addition, Product is not warranted against failure, and should not be used by Customer for any application where (i) there is a risk that any data stored on Product will be breached or otherwise compromised, or (ii) the data stored on Product is relied upon for medical or lifesaving applications. QFX disclaims any Warranty for any of the foregoing uses to the fullest extent permitted by law. Customer assumes any and all risks associated with such uses of Product, and agrees to indemnify QFX for any damages claimed against QFX for such uses.

EXCEPT FOR EXPRESS WARRANTIES STATED ABOVE AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, THE PRODUCTS ARE PROVIDED "AS IS" AND QFX DISCLAIMS ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY (i) OF MERCHANTABILITY, (ii) OF FITNESS FOR A PARTICULAR PURPOSE, OR (iii) OF NON-INFRINGEMENT OF THIRD PARTY RIGHTS. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL QFX BE LIABLE TO CUSTOMER OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, ANY LOST PROFITS OR REVENUES, LOSS OR INACCURACY OF ANY DATA OR COST OF SUBSTITUTE GOODS, REGARDLESS OF THE THEORY OF LIABILITY (INCLUDING NEGLIGENCE) AND EVEN IF QFX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, QFX AGGREGATE LIABILITY TO CUSTOMER FOR ACTUAL DIRECT DAMAGES FOR ANY CAUSE WHATSOEVER SHALL BE LIMITED TO THE CUMULATIVE PRODUCT FEES PAID BY THAT CUSTOMER FOR THE PRODUCTS CAUSING THE DAMAGES, IF ANY.

This Warranty gives Customer specific rights, and Customer may also have other rights that vary from jurisdiction to jurisdiction. Warning: Some Products may contain components that are small enough to be swallowed. Please keep out of reach of children. In order for the return to be processed, you must send the Product PREPAID to the address below in the original packaging or reasonable substitute to prevent damage and include: (1) a dated sales receipt (which must have a purchase date that falls in the Warranty Period specified in the table below) that indicates the place of purchase, model number of Product, and amount paid, (2) a detailed description of Customer's problem with Product, (3) Customer's full name, phone number, and return address, (3) all of the accessories that came with the Product package must be sent along with the main Product, (4) a cashier's check or money order payable to QFX, Inc., in the amount specified for the item in the product table below for return shipping and handling. If in the case you cannot provide a money order or cashier's check, you can contact The QFX Customer Support Representative to arrange payment via credit card. No returned Product will be shipped back to a PO BOX. If a returned Product is found to have no problem and/or does not include ALL of the requirements indicated above, it may be returned back to the customer and will not be processed.


BT-2010


QFX USA®, Inc.

RMA Processing


Customer Support Department

2957 E. 46th Street | Vernon, CA 90058

 support@qfxusa.com

 (800) 864-CLUB (2582) or (323) 864-6900

 qfxusa.com

 Hours of Operation: Monday - Friday, 9am - 5pm PST

All prices and details below are for US Destinations excluding, Hawaii, Alaska and Puerto Rico. For excluded destinations and NON US destinations, please contact The QFX Customer Support Department directly for additional shipping fees and return instructions.

If you do not find your Product below, your Product model conflicts with multiple categories, and/or are unsure of which category the Product you have purchased will fall under, please contact our Customer Support Department for further instruction.

In order to determine the exact shipping cost that must be included with your product or paid for the product being returned, please refer to the table below. Please find the product you wish to return by category or model number prefix. QFX will not provide any return or refund to any customer for merchandise and will only honor the Limited Warranty restrictions mentioned in this document.

Please make sure to follow all directions prior to shipping back your item. If you are not sure what the shipping cost for your item is, or if your item category conflicts in the table below, please feel free to contact the QFX Support Department for further assistance.

PRODUCT CATEGORY	HANDLING	LABOR	PARTS
Earphones, Headphones, Pocket Radios, & Small Bluetooth vSpeakers	\$5.00	1 Year	1 Year
Personal Stereos	\$10.00	1 Year	1 Year
Portable Radio/Cassette	\$15.00	1 Year	1 Year
Large Portable Radio Cassette	\$20.00	1 Year	1 Year
Mobile Audio	\$10.00	1 Year	1 Year
Pro Audio SBX Systems	\$75.00	1 Year	1 Year
Pro Audio PBX Systems	\$75.00	1 Year	1 Year
Televisions	\$25.00	1 Year	1 Year
Telephones	\$10.00	1 Year	1 Year

THE WARRANTY AND REMEDY PROVIDED ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESSED OR IMPLIED WARRANTIES INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE. SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESSED OR IMPLIED WARRANTIES ARE LIMITED TO THE WARRANTY PERIOD IDENTIFIED ABOVE. UNLESS STATED HEREIN, ANY STATEMENT OR REPRESENTATIONS MADE BY ANY OTHER PERSONS OR FIRM ARE VOID. EXCEPT AS PROVIDED IN THIS WRITTEN WARRANTY, QFX SHALL NOT BE LIABLE FOR ANY LOSS, INCONVENIENCE, OR DAMAGE, INCLUDING DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, RESULTING FROM THE USE OR INABILITY TO USE THE QFX PRODUCT, WHETHER RESULTING FROM BREACH OF WARRANTY OR ANY OTHER LEGAL THEORY.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, and some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you special legal rights and you may have other rights which vary from jurisdiction to jurisdiction.

Copyright Protected 2023 ©



1-800-864-CLUB (2582)
Mon-Fri 9AM - 5PM (PST)



support@qfxusa.com
Mon-Fri 9AM - 5PM (PST)



www.qfxusa.com

THANK YOU.

WHERE THE PARTY BEGINS™

We would love to hear about your BT-2010 journey!
Tag us @QFXUSA to share your stories.