

WIRELESS REMOTE SHUTTER

USER
MANUAL

PRODUCT PARTS INTRODUCTION

- 1. Light Indicator
- 2. Shutter Button
- 3. On/Off Button
- 4. Lanyard Strap Handle
- 5. Lanyard Strap



HOW TO SET UP


1. Go to your smartphone's Bluetooth settings. (Bluetooth should be set to "ON").
2. Turn the On/Off switch to the "ON" position on the remote shutter (slide up).



NOTE: Switch to "OFF" when not in use to save battery life

HOW TO SET UP

3. You will see a blinking Blue light on the shutter button which indicates that the remote shutter is now discoverable by your smartphone.



4. Pair with phone by choosing "Bower Shutter" on the Bluetooth settings menu. Remote is now ready for use.

HOW TO USE

1. Open up your camera app on your smartphone and press the Shutter Button on the remote to take photos or record videos. For recording video press once to record, then again to stop.



SPECIFICATION

Frequency:	2.4 Hz-2.4835 GH
Effective distance:	10m (30ft)
Battery model:	CR2032 x 1 cell
Size:	1.97" x 1.3" x 0.4

LIMITED One (1) Year Limited Warranty

S. Bower Inc.™ One (1) Year Limited Warranty: This warranty gives you specific legal rights and you may have other rights which vary from state to state.

The S. Bower Inc.™ Limited Warranty is a voluntary manufacturer's warranty provided to the consumer. This warranty provides rights separate to rights provided by consumer law, including but not limited to those relating to non-conforming goods. S. Bower Inc.™ One-Year Limited Warranty benefits are in addition to, and not instead of, rights provided by consumer law and it does not exclude, limit or suspend a buyer's rights arising from consumer law. Consumers have the right to choose whether to claim service under the S. Bower Inc.™ One-Year Limited Warranty or under their consumer law rights. The S. Bower Inc.™ One-Year Limited Warranty terms and conditions shall not apply to consumer law claims, contact your local consumer organization.

Please note: All claims made under the S. Bower Inc.™ One-Year Limited Warranty will be governed by the terms set out in this warranty document.

S. Bower Inc.™ warrants to the product owner that this product will be free against defects in materials and workmanship for a period of ONE (1) YEAR from the date of original retail purchase when used in accordance with S. Bower Inc.™'s user manual. Under this warranty, you will be able to send your claims and defective product to S. Bower Inc.™, via freight prepaid, along with proof of purchase, and will be repaired or replaced, based on S. Bower Inc.™ sole discretion. Repair and/or replacement may be made with new or refurbished product components at S. Bower Inc.™ sole discretion. This limited warranty does not cover failures due to abuse, accidental damage or when repairs have been made or attempted by anyone other than S. Bower Inc.™ personnel. A defective product meeting the warranty conditions set forth herein will be replaced or repaired at no charge in either of two ways. The first, which will result in exchanges only, is to return the product to the retailer from whom it was purchased (provided that the store is a participating retailer). Returns should be made within the time period of the retailer's policy for exchanges. Proof of purchase may be required. Please check with the retailer for its specific return policy regarding time limits for returns or exchanges. The second option is to send the product (prepaid freight) to S. Bower Inc.™ corporate offices located at S. Bower Inc. 46-24 28th Street 3rd Floor Long Island City, NY 11101 for repair or replacement at S. Bower Inc.™'s option. Proof of purchase is required. Include name, return address, and issues that you are experiencing with S. Bower Inc.™ products. All other guarantees, express or implied, are hereby disclaimed.

This warranty does not cover products sold outside of the United States.

