

WHITE/RGB TRI-FOLD LIGHT

WITH WIRELESS REMOTE CONTROL



USER MANUAL

IN THE BOX:



Tri-fold Light

Wireless Remote

USB-C Charging Cable

HOW TO SET UP (Tri-fold Light)




Back side

Recommended:
Fully charge before using

STEP 1:

Fully charge before using (recommended). Connect the provided USB charging cable to any USB port to begin charging. A Blue color light will appear to blink on the control panel to notify charging is in progress. Continue charging until the Blue LED light stops blinking.

HOW TO USE (Tri-fold Light)



Closed

Open


STEP 1:

The Tri-fold light can be used in closed position and open/extended position. To open up, simply pull out the light panels using the finger grooves located on each panel.

NOTE: The light panels of the Tri-fold light are configurable. Various configurations can be made based on your needs.

HOW TO USE (Tri-fold Light)

Works with Tripods:
Universal 1/4" thread located underneath.



STEP 1:

Simply screw-in Tri-fold light into your tripod. Universal 1/4 inch thread allows for compatibility with most tripods.

HOW TO USE (Tri-fold Light)

Control Panel



LED-Light

Indicates charging progress

Power Button/ Mode Switch

Long press (hold for 3 seconds): Powers ON/OFF

Short press (press without holding down): Switches between RGB colors/ RGB special effects/White Light modes

Brightness Button/

Increases/Decreases brightness

HOW TO USE (Tri-fold Light)

Using the Remote

On Button
Powers On Light

Off Button
Powers Off Ring Light

Mode Button
Click repeatedly to cycle through White, Natural, Warm Light

Brightness Up
Increases brightness


Brightness Down
Decreases brightness

Changes brightness/
Changes speed during
Special Effect modes.
To adjust brightness
of Special Effects use
control panel button.

Changes brightness/
Changes speed during
Special Effect modes.
To adjust brightness
of Special Effects use
control panel button.

RGB Mode Button
TURNS ON RGB MODE

Click repeatedly to
change between
9 RGB colors and
8 Special Effects





IMPORTANT: Remove clear battery discharge film before use.


NOTE: The Wireless Remote comes pre-installed with battery.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

9 DIFFERENT RGB COLORS



8 RGB SPECIAL EFFECTS



3 WHITE LIGHT MODES



FEATURES:

- Choose from 9 different RGB colors, 8 Special Effects and 3 White Light modes
- Includes adjustable brightness
- Expanding light panels for versatile use
- Tripod mountable design
- Built-in rechargeable battery: Simply plug into a USB port (Computer/Laptop, Wall Charger, Portable Power Bank) to charge
- Great for Vlogging, Live Videos, Video Chats, Social Media, Live Streaming, and more
- Portable on-the-go design

SPECIFICATION:

LED Beads: 102pcs total
Lumen: 1000 LM
CRI: ≥70RA
Color Temperature: 3000-6000K
Power: 20W
Size(closed): 1.7 in x 1.7 in x 7.3 in
Light Modes: RGB, White, Natural, Warm

Disclaimer:

This manual should be kept for future reference and maintenance purposes only. Be sure to review this manual and become familiar with its features before using this product. Please make sure to never change the light bulb while plugged into an outlet or other power source. Do not open or change wiring in anyway. Keep this product away from children. Clean this product often with a soft, dry cloth. This product shall ONLY be used with rated voltage and frequency. Do not try and alter power supply or adjust voltage. Avoid unplugging the power by pulling the power cord and do not touch the power cord with wet hands. Never attempt to insert any metal objects into the cooling holes of illuminators. Avoid moving the illuminator by pulling the power cable. Stop using this product if the unit is damaged, especially the power cord. Do not use in the rain, bath, or near water source. Please be aware that improper use or inappropriate repair can lead to fire or electrocution. Indoors use only. Please send back to Bower or contact customer service for issues regarding maintenance or repair. Make sure everything is secure before proceeding. Make sure the product is intact and that there are no missing parts. All photos and illustrations are for instruction purposes only.

LIMITED One (1) Year Limited Warranty
S. Bower Inc.™ One (1) Year Limited Warranty: This warranty gives you specific legal rights and you may have other rights which vary from state to state.

The S. Bower Inc.™ Limited Warranty is a voluntary manufacturer's warranty provided to the consumer. This warranty provides rights separate to rights provided by consumer law, including but not limited to those relating to non-conforming goods. S. Bower Inc.™ One-Year Limited Warranty benefits are in addition to, and not instead of, rights provided by consumer law and it does not exclude, limit or suspend a buyer's rights arising from consumer law. Consumers have the right to choose whether to claim service under the S. Bower Inc.™ One-Year Limited Warranty or under their consumer law rights. The S. Bower Inc.™ One-Year Limited Warranty terms and conditions shall not apply to consumer law claims, contact your local consumer organization.

Please note: All claims made under the S. Bower Inc.™ One-Year Limited Warranty will be governed by the terms set out in this warranty document. S. Bower Inc.™ warrants to the product owner that this product will be free against defects in materials and workmanship for a period of ONE (1) YEAR from the date of original retail purchase when used in accordance with S. Bower Inc.™'s user manual. Under this warranty, you will be able to send your claims and defective product to S. Bower Inc.™, via freight prepaid, along with proof of purchase, and will be repaired or replaced, based on S. Bower Inc.™ sole discretion. Repair and/or replacement may be made with new or refurbished product components at S. Bower Inc.™ sole discretion. This limited warranty does not cover failures due to abuse, accidental damage or when repairs have been made or attempted by anyone other than S. Bower Inc.™ personnel. A defective product meeting the warranty conditions set forth herein will be replaced or repaired at no charge in either of two ways: The first, which will result in exchanges only, is to return the product to the retailer from whom it was purchased (provided that the store is a participating retailer). Returns should be made within the time period of the retailer's policy for exchanges. Proof of purchase may be required. Please check with the retailer for its specific return policy regarding time limits for returns or exchanges. The second option is to send the product (prepaid freight) to S. Bower Inc.™ corporate offices located at S. Bower Inc. 38-09 43rd Avenue 1st Floor Long Island City, NY 11101 for repair or replacement at S. Bower Inc.™'s option. Proof of purchase is required. Include name, return address, and issues that you are experiencing with S. Bower Inc.™ products. All other guarantees, express or implied, are hereby disclaimed.

This warranty does not apply to products sold in countries sold out of the United States.