



thanks so much for choosing our new ErgoBoost! we put an awful lot of time (and caffeine) into this one, and are super proud of what we accomplished. we believe it is the most advanced booster on the market today. as with all our products, it comes with a LIFETIME guarantee.

hiccapop prides itself on stellar customer service. if you ever have a question about anything, just drop us a note and one of our energetic gen z'ers will quickly get back to you with an answer.



now for our favorite part... our shameless plug for reviews!

for us, amazon reviews are as important to our success as a good night's sleep is to a new parent, because they help spread good hiccavibes across America. so if you could please take a minute to review your ErgoBoost, we'd sure appreciate it. and to make it really easy (which is important when kissing up like this), all you have to do is go to amazon.com/ryp to leave your review.

info@hiccapop.com



www.hiccapop.com



product instructions

assembly:

there is no assembly actually.

instructions:

(even ours can be boring, so we've tried to keep them short.)

while our ErgoBoost requires NO assembly, it does require that you securely fasten the safety straps to your chair so your little one doesn't take a nosedive.

washing:

if your child has a major spill, just hose down the entire unit.

final word:

we hope you love your ErgoBoost as much as we loved designing it! it oughta outlast your children (and grandchildren) because it's built to last forever. and if you like us, please spread the word!

keep an eye out for a lot of new hiccastuff coming out soon!

peace, joy, tranquility
hiccapop

adult chair minimum dimensions: 18" wide x 14" length x 14" backrest height

WARNING

Children have suffered **head injuries**, including skull fractures, **after falling** with or from booster seats.

- Check that ErgoBoost is **securely attached** to adult chair before each use.
- **Always use restraints** until child is able to get in and out of ErgoBoost without help. Adjust to **fit snugly**.
- **Never** allow child to **push away from table**.
- **Never lift** and **carry** child in ErgoBoost.
- **Stay near** and **watch** your child during use.

Prevent falls from adult chairs:

Securely attach ErgoBoost using **all** provided safety straps (under and behind).

WARNING

Until Child is able to get in and out of the ErgoBoost without help (about 2 ½ years old), the child should be secured in the booster seat at all times by the restraining system. The tray is not designed to hold the child in the chair.

WARNING

Use this product only for children capable of sitting upright unassisted.

WARNING

Prevent serious injury or death:
Do not use in motor vehicles.

**This insert card is
6.25 inches wide x
7.25 inches tall**

**Red lines are the card shape, do not print
red lines; red circle is hole for hanging card.**