front



thanks so much for choosing our OmniBoost - America's #1 child booster. we call it the "go anywhere, use anywhere" booster. with its unmatched stability, (removable) stain resistant fabric, a swiveling food tray, and even a LIFETIME guarantee... we believe it is the most advanced booster on the market today.

hiccapop® prides itself on stellar customer service. if you ever have a question about anything... just drop us a note and one of our team members will quickly get back to you with an answer.



now onto our favorite part...
our shameless plug for reviews!

for us, amazon reviews are as important to our success as a good night's sleep is to a new parent, because they help spread good hiccavibes across America. so if you could please take a minute to review your OmniBoost, we'd sure appreciate it. and to make it really easy (which is important when kissing up like this), all you have to do is go to amazon.com/ryp to leave your review.

info@hiccapop.com

www.hiccapop.com



5.5 inches wide

back

product instructions

assembly:

instructions (even ours) can be boring, so we've tried to keep them short:

- 1. remove OmniBoost from bag, unfold, and lock rear legs into place.
- **2. securely** fasten the safety straps around adult chair and insert your little one.
 - A. for increased stability (perhaps you're out at a park or a beach), try using our "duck-feet". they slide over the normal feet and help prevent tip-overs... like those that happen when your great dane decides to sit in your baby's lap at lunchtime.
- 3. to attach the tray, simply drop it into place over the small mushroom-shaped heads on either side of the chair arms. ensure the tray is firmly locked down. to fully remove or to swivel the tray, pull out one or both of the side levers, and you are good to go.

washing:

- 1. remove the tray.
- 2. remove the cover.
 - **A. it's** easier to remove the cover if your OmniBoost is partially collapsed.
 - **B.** remember to unhook the elastic straps at the base of each fabric corner.
 - **C. the** cover is tight on purpose, but the holes are definitely large enough to fit over the posts.
- **3. machine** wash cover (no bleach!) using cold setting, allow to air dry.

final word:

we hope you love your OmniBoost as much as we loved designing it. lots of hours (and caffeine) were put into its design, and we are incredibly proud of it. look for more new things from us soon! and please, if you like hiccapop® - spread the word.

adult chair minimum dimensions: 17" wide x 17" length x 18" backrest height

A WARNING

Children have suffered **head injuries**, including skull fractures, **after falling** with or from booster seats.

- Check that OmniBoost is securely attached to adult chair before each use.
- Always use restraints until child is able to get in and out of OmniBoost without help. Adjust to **fit snugly**.
- Never allow child to push away from table.
- Never lift and carry child in OmniBoost.
- Stay near and watch your child during use.

Prevent falls from adult chairs:

Securely attach OmniBoost using **all** provided safety straps (under and behind).

A WARNING

Until Child is able to get in and out of the OmniBoost without help (about 2 ½ years old), the child should be secured in the booster seat at all times by the restraining system. The tray is not designed to hold the child in the chair.

A WARNING

Use this product only for children capable of sitting upright unassisted.

A WARNING

Prevent serious injury or death: Do not use in motor vehicles.