

**How to install W160C** onto the webcam

#### Foreword

Thanks for your purchasing.

#### Instructions

- · Please read this product manual carefully.
- · Always keep this manual. When passing the product to the third parties, please include this manual.
- · Pay attention to all the warnings and follow all the instructions.

# **MARNING**

Do NOT place the product on corrosive places, which will lead to malfunction.

- · Only use a dry microfiber cloth for cleaning.
- Operate the product carefully, prevent it from damage of dropping or physical shocking.
- Do NOT place the product near to high temperature, which will cause
- Please check the product by authorized engineer if necessary. The warranty does NOT apply to malfunctions that caused by repairing with non-original accessories, not even a chargeable basis.
- . The product has CE and RoHS certified. Please operate the product under the compliance and standards.
- · The instruction and information in this manual are based on thorough testing procedures by manufactory. Further information might not be given if the design and specification change.

## **Applicable Conditions**

- The user has read this manual carefully;
- The use is using the product within operating conditions and limitations as described in manual;
- "Improper use" means using the product in conditions and limitations that undescribed in manual.


# **Packing List**







Product Overview:



## Instructions:

1.Power off/Mode Switch



Long press to turn on the light

# 2.Display Zone CCT Mode





Toggle the Mode Adjust Thumbwheel to adjust the Color Temperature

Toggle the Brightness Adjust Thumbwheel to adjust the brightness Range: 0-100%

## **Product Specification:**

	Color Temperature	2500-6500K	
PCS		Strongest Brightness>2h	
PCS	Work Time	Weakest Brightness>15h	
	Power	8W	
	Charge Port	Type-C	
ı	Beam Angle	120°	
	0.3m	0.5m	1m
ss	1150LUX	550LUX	180LUX
		ss 1150LUX	

<sup>\*</sup> The data of the light is on the base of average, slight difference shall

### Warranty

We offer one-year product warranty.

### Important

Keep the original sales receipt. Make sure that the seller has written the purchase date, serial product number on the receipt. These information will be required for warranty service.

#### The Warranty Does NOT Cover

- Damages by incorrect operation, incorrect connection, accident (including but not limited the damage by water), or the improper use with unintended
- Defects on decorations (including defects caused by improper handling) that appear after 30 days of purchase date;
- Damages by shipping to the third parties.

### The Warranty Will Be Invalid If

- The product identification or serial label is removed or defaced;
- The product is repaired or disassembly by any one other than an authorized dealer or agency.

#### GUARANTEE CARD

Serial No.	
Item Name	
Purchase Date	
Buyer Name	
Buyer Phone	
Buyer Add	
Franchiser Seal	


# Step 1

Install the base mount onto the webcam



# Step 2

Remove the W160C cold shoe base cover



# Step 3

Install the LED light onto the base mount



The webcam is connected to the light through the base mount then can use together.

