



**MESH LINKABLE
LIGHTING**


LINKABLE SOLAR POWER SECURITY WALL PACK (4-PACK)

ES00945G/ES00946G/ES00947G
INSTALLATION INSTRUCTIONS

ES00945G
BLACK



ES00946G
BROWN




ES00947G
SILVER



What's in the box


Tools required for assembly (not included): phillips screwdriver, safety goggles, power drill and ladder.



4 Light Fixture



4 x 2 Plastic Anchor



4 x 2 Mounting Screw

Specifications

- 01 Dimension: approx. 7.24inch x 2.83inch x4.09inch
- 02 Wireless transmit distance: up to 160feet
- 03 Illumination output: approx. 800 lumens / 3,000K
- 04 Sensor detect range: 26 feet x 120 degree
- 05 Power source: 1 x 3.7V 1,500mAh 18650 Lithium battery

Location


Fixture can be wall mounted.

Recommended installation height: 4.5~8 feet. (1.2m~2.4m) above the ground.

Environment will affects the sensor range. It is recommended not to mount the fixture near a heat source like an air conditioner, vent, or furnace exhaust, or in a direction facing a light reflecting object.

Maybe the sensor detection distance will decrease lower than 26 feet in some special environment.

Warning

 **WARNING:** This product can expose you to chemicals including lead and lead compounds, Di (2-ethylhexyl) phthalate (DEHP), which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warning.ca.gov.

Please Read Carefully and Save These Instructions, As You May Need Them at A Later Date.

IMPORTANT SAFETY OPERATING INSTRUCTIONS

- 01 Please read all warning and instruction labels which are included in the box and fixture to avoid personal injury, property damage caused by fire, cuts, bruises, death and other dangers.
- 02 Please follow these general precautions before installing, maintaining, or fixing.

WARNING

- 01 The packing contains small parts that could be swallowed by children
- 02 Keep the packaging material away from children and pets
- 03 **DO NOT** look directly at the LED lights.
- 04 This light fixture is NOT A TOY and is not suitable children.
- 05 We do not take responsibility if the instruction manual is not followed correctly or if the product is handled improperly resulting in damage to person or property
- 06 The operating temperature of solar wall light is between -4° F (-20° C) and 122° F (50° C).
- 07 Rechargeable battery only. Recycle or dispose of battery properly.
- 08 Do not open, short circuit, or mutilate battery. Injury may be occurred.

PRECAUTION


- 01 This light fixture should be installed outdoors to a wall.
- 02 Do not immerse the light fixture in liquid.

Installation


* Prior to using your solar wall light ,initial charge is needed and it should be done in the OFF position for at least three sunny days. After the third day,the included battery will be enough power for operation of solar wall light.

Recommended installation height: 4.5 ~ 8 feet above the ground.


At such a height, The fixture will provide a detection distance of up to 26 feet (Max) at ambient temperature of 77 degrees Fahrenheit. The sensor will be more sensitive to motion across than motion towards it directly.




- 01** To mount the solar wall light to a concrete or brick wall, use the template at the back of light to mark the mounting screw locations. Alternatively, measure and mark the installation locations for the mounting screws 4.72 in. (120 mm) on-center.




- 02** Drill two 7/32 inch holes on the wall at the marked locations.



- 03** Insert the plastic anchors into the holes. Screw the mounting screws into the anchors, leaving about 1/4 inch of the screws sticking out of the wall surface.



- 04** Align and place the two mounting holes on the back plate of the solar wall light over the mounting screws.



How it works


Please slide the OFF-ON switch to "ON" position before install your solar wall light as above.

While slide the OFF-ON switch to **ON** position the light will turn on and enter a "warm-up" period, the light illuminates automatically at night using an energy saving mode of low brightness. When motion is detected at night, the light illuminates at full brightness for approximately 20 seconds.

This series linkable light can be linked together while change the mode switch to ON mode and at same channel. No need link set-up in advance.

MESH LINKABLE LIGHTING Channels (CH1/CH2/CH3/CH4) Setting:

This setting is used to link the light fixture to the other Home Zone Security MESH LINKABLE LIGHTING products. You can select the same channel (4 channels option) of your others Home Zone Security MESH LINKABLE LIGHTING products to form a group, then these products will function together as a group.



Cleaning and Maintenance

The solar panel should be cleaned periodically, clean the light fixture or solar panel with a soft, damp cloth. Do not use paints, solvents, or other chemicals on this light fixture. They could cause a premature deterioration of the finish.

Rechargeable Battery

01 Use 1pc 3.7V 18650 1,500mAh Lithium rechargeable battery. For best performance, replace with Lithium battery rechargeable battery annually.

IMPORTANT: Dispose of the battery in accordance with local, state, and federal regulations.


IMPORTANT: When storing any solar product for an extended period of time, remove the battery. Storing any solar product without regular recharge or removal of battery could cause permanent damage to the rechargeable battery.

For best performance, replace with the new Lithium rechargeable battery every 18 months. When the battery expires, it must be recycled or disposed of properly. Please contact your local waste disposal authority for correct procedure. Do not put battery into fire.

- Only rechargeable batteries are to be used.
- Exhausted batteries must be removed from the product.
- Batteries must be placed at the correct polarity.

02 Battery replacement

- Loosen the locking screw on the bottom of the base of the light fixture, remove the battery compartment cover.
- Remove the old battery from the battery compartment. Replace with new 3.7V 18650 1,500mAh Lithium rechargeable battery.
- Make sure the polarity is correct.
- Replace the back plate to the light fixture housing with the locking screw.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with FCC Part 15 of FCC Rules.

- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement: This equipment complies with FCC RF Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

Get exclusive offers and deals when you subscribe!

Thank you for choosing Home Zone Security!
We are here to support you every step of the way.


Please be sure to contact our customer support for troubleshooting and register your product for additional benefits. Products must be sold by an authorized reseller or distributor to be valid.

Why Register?

- Receive your extended warranty
- Get professional warranty support
- Be the first to hear the latest product news.
- Get exclusive deals delivered to you email.



Customer Service
homezonesecurity.com
support@homezone-usa.com
+1 888-782-5618

Distributed by
Horizon Marketing Group, LLC 
4198 Industry Way, Flowery Branch, GA 30542
MADE IN CAMBODIA